




US PAT# 11,728,579 CAN PAT # PENDING

### Install instructions for I-Plate

1. Dig hole per CSA/CES placing plate @ 600mm+ below finished grade of floor
2. Place 2x4 under ground plate
3. Place both feet on plate
4. Grasp the leg at its midpoint with both hands
5. Stand up while holding leg until it is perpendicular to plate
6. Place plate in hole, at minimum depth of 600mm below finished floor surface level
7. Bury plate and connect as per code



C22.1-18 Section 10  
Grounding and bonding

### 10-102 Grounding electrodes (see Appendix B)

- 1) Grounding electrodes shall consist of
  - a) manufactured grounding electrodes
  - c) in the case of a plate electrode, be
    - i) in direct contact with exterior soil at **not less than 600 mm below grade level**; or
    - ii) encased within the bottom 50 mm of a concrete foundation footing in direct contact with the earth at **not less than 600 mm below finished grade**.

